




# Zeki TBQG884B LCD Screen Replacement

This guide assists you to replace the LCD screen of Zeki TBQG884B 8" Tablet.

Written By: David Wyman



## INTRODUCTION

This guide will help you through the step-by-step process of replacing the LCD screen. The screen is connected directly to the motherboard and assembled with the front frame. You can look at the teardown guide for the device to learn how to teardown it.

---



### PARTS:

- [Replacement Zeki LCD Display](#) (1)
-

## Step 1 — Rear Case



- Remove the two screws from the end of the device where the ports are located.


## Step 2



- Rest the tablet on its glass face.
- Insert the tip of a plastic opening tool into the small gap between grey and white plastic and pry open (You should hear the clips opening up).
- Gently work your way around the parameter of the tablets edge.




## Step 3



- Remove back plate from the face plate.
- Remove the tape from speaker and detach speaker from back plate.


⚠ The speaker is connected to the motherboard by two soldered wires. Don't break them when you remove the speaker.

## Step 4 — Motherboard




- Remove the Wi-Fi antenna element, which is highlighted by red in the picture, from the front plate.

## Step 5



- Use the same screw driver for teardown to move three screws as shown in the picture.


## Step 6



- Open the ZIF connector, the black locker part over the wire ribbon in the motherboard and remove the wire ribbon which connects the motherboard and the screen.




## Step 7



- Remove the other wire ribbon on the other side of the motherboard.


## Step 8



- Now you can remove the motherboard and replace with a new one.


⚠ Be careful not to damage the battery and speaker wires which are soldered on the motherboard.

## Step 9 — LCD Screen



- Use the pry bar to detach the click between the front frame and metal loader.
- ⓘ There are several clicks on each side of the frame. Detach ALL of them before you open the loader.

## Step 10



- Open the loader and detach the LCD screen.
- ⚠ There are 3 separate unconnected screens. Be careful not to let any drop out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-10 08:38:42 PM.